

SONY

3-861-298-22 (1)

Portable MiniDisc Recorder

Operating instructions



MZ-R50

© 1997 by Sony Corporation

WARNING

To prevent fire or shock hazard, do not expose the unit to rain or moisture.

To avoid electrical shock, do not open the cabinet. Refer servicing to qualified personnel only.

Caution

The use of optical instruments with this product will increase eye hazard.

Information

For Customers in the USA

This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

You are cautioned that any changes or modifications not expressly approved in this manual could void your authority to operate this equipment.

The built-in battery should be replaced by qualified personnel only.

For Customers in Australia

If the supply cord of AC power adaptor is damaged, the AC power adaptor must be returned to the manufacturer or his agent for the cord to be replaced.

For the customers in the USA

DISPOSAL OF LITHIUM ION BATTERY
LITHIUM ION BATTERY. DISPOSE OF PROPERLY.

You can return your unwanted nickel lithium ion batteries to your nearest Sony Service Center.

Note: In some areas the disposal of lithium ion batteries in household or business trash may be prohibited.

For the Sony Service Center nearest you call 1-800-222-SONY (United States only).

Caution: Do not handle damaged or leaking lithium ion battery.

IN NO EVENT SHALL SELLER BE
LIABLE FOR ANY DIRECT,
INDIRECT OR CONSEQUENTIAL
DAMAGES OF ANY NATURE, OR
LOSSES OR EXPENSES RESULTING
FROM ANY DEFECTIVE PRODUCT
OR THE USE OF ANY PRODUCT.

Owner's Record

The serial number is located at the rear of the disc compartment lid and the model number is located at the bottom. Record the serial number in the space provided below. Refer to them whenever you call upon your Sony dealer regarding this product.

Model No. MZ-R50

Serial No. _____

"MIO WALKMAN" is a trademark of Sony Corporation.

Welcome!

Welcome to the world of the MiniDisc. Here are some of the capabilities and features you'll discover with the new MiniDisc Recorder.

- Shock-resistant memory — Offsets up to 40 seconds of optical read errors.
- Easy operation with the new remote control — Keep the main unit in your pocket and operate the MiniDisc player through the shuttle dial on the remote control. The LCD displays track information, playback mode as well as battery condition.
- High-fidelity recording — Low-noise, low-distortion, high-fidelity recording through the optical digital input jack.
- Vertical jog dial — You can select your desired tracks directly by simple rotating a dial.
- Digital sync/line recording — The recorder automatically starts and pauses recording in sync with operation on the connected digital equipment.
- Sampling rate converter — This unit enables you to record programs from digital equipment using other sampling rates, such as a 16s timer on DAT deck.
- Long time recording with manual sound — You can record up to 18s minutes on a disc using manual recording.
- Position pointer — The display shows you the current location on the disc.
- Date and time stamp function — The built-in clock automatically records the date and time whenever you make a recording.
- Title function — You can see disc and track titles in the display while you are playing/recording an MIO.

Table of Contents


Recording an MD right away!	6
Playing an MD right away!	8
Various ways of recording	10
Two ways of connecting to a sound source	10
Recording with digital input	11
To start/stop recording in sync with the source player (Synchronizing)	11
Recording from a microphone	12
Recording in monaural for double the normal recording time	13
Adjusting the recording level manually (Manual recording)	13
Checking the remaining time or the recording position	14
On the recorder	14
On the remote control	15
Setting the clock to stamp the recorded time	16
Various ways of playback	17
Selecting the track number or track name directly	17
Playing tracks repeatedly	17
Emphasizing bass (DIGITAL, MEGA BASS)	18
Protecting your hearing (AVT 5)	18
Checking the remaining time or the playing position	19
On the recorder	19
On the remote control	19
Locking the controls (LOCK)	20
Connecting to a stereo system	20

Editing recorded tracks	21
Erasing tracks	21
To erase a track	21
To erase the whole disc	21
Adding a track mark	22
Erasing a track mark	22
Moving recorded tracks	23
Labeling recordings	23
Power sources	25
Using a lithium ion rechargeable battery	25
Using dry batteries	26
Additional information	27
Precautions	27
Troubleshooting	29
System limitations	31
Messages	32
Specifications	34
What is an MD?	35
Looking at the controls	37

Recording an MD right away!

Sound from CD players, cassette recorders, etc., will be sent analogically, but recorded digitally, in stereo. To record from a digital source, see "Recording with digital input" (page 11).

Make connections.




Insert a recordable MD.



① Slide OPEN and open the lid

② Insert a recordable MD with the label side facing up, and press the lid down to close.

Record an MD.



- ① Press and slide REC to the right. "REC" lights up and recording starts.
- ② Play the CD or tape you want to record.

To stop recording, press ■.

"Data Save" or "Loc Edit" flashes while data of the recording (the track's start and end points, etc.) is being recorded. Do not move or jog the recorder or disconnect the power source while the indication is flashing in the display.

To

Pause

Record from the end of the previous recording.

Record partway through the previous recording.

Remove the MD

- ① A track mark is added at the point where you press ■, thus the remainder of the track will be control as a new track.
- ② Once you open the lid, the point to start recording will change to the beginning of the first track (the point to start recording on the display).

If the recording does not start

- Make sure the recorder is not locked (page 20).
- Make sure the MD is not record-protected (page 28).
- Premastered MDs cannot be recorded over.




The level of the recorded sound is adjusted automatically.

- You can monitor the sound during recording. Connect the supplied headphones with remote control to REMOTE and adjust the volume by pressing VOL (LINE +/-) (VOL +/- on the remote control). This does not affect the recording level.


Playing an MD right away!

To use the recorder on a rechargeable battery or dry batteries, see "Power Sources" (pages 25, 26).


Make connections.



Insert an MD.



Play an MD.



① Press ► (Turn the control to ►►► on the remote control).
A short beep sounds in the headphones.

② Press VOLUME (VOL on the remote control) +/- to adjust the volume.
The volume will be shown in the display.

To Press (Beeps in the headphones)

Pause ■ (continuous short beeps; Press ■ again to resume play)

Find the beginning of the current track
►►► once (Turn the control to ►►► on the remote control)
(Three short beeps)

Find the beginning of the next track
►►► once (Turn the control to ►►► on the remote control)
(Two short beeps)

Keep pressing ►►► (Turn and hold the control to ►►► on the remote control)

Keep pressing ►►► (Turn and hold the control to ►►► on the remote control)

Keep pressing ►►► (Turn and hold the control to ►►► on the remote control)

Keep pressing ►►► (Turn and hold the control to ►►► on the remote control)

Keep pressing ►►► (Turn and hold the control to ►►► on the remote control)

Remove the MD)

Go backward or forward quickly without listening; press ■ and keep pressing ►►► or ►►►

Once you open the lid, the point to start play will change to the beginning of the first track

If the play does not start

Make sure the recorder is not locked (page 20).

When using optional headphones

Use only headphones with stereo mini plugs. You cannot use headphones with mini-plugs.

Play back will switch automatically between stereo and mono according to the sound source.

► Various ways of recording

Two ways of connecting to a sound source

The input jack of this recorder works as both digital and analog input jacks. Connect the recorder to a CD player or a cassette recorder using either digital input or analog input. To record, see "Recording with digital input" (page 11) to record using digital input, and "Recording an MD right away" (page 6) to record using analog input.

Difference between digital and analog inputs


Difference	Input	Digital input	Analog (line) input
Connectable source		Equipment with an optical digital output jack	Equipment with an analog (line) output jack
Cable cord		Digital cable (with an optical or an optical-mini plug)	Line cable (with 2 phono plugs or a stereo-mini plug)
Signal from the source		Digital	Analog Even when a digital source (such as a CD) is connected, the signal sent to the recorder is analog.
Recorded track numbers		Marked (copied) automatically • at the same positions as the source. • when the recorder is paused while recording.	Marked automatically • after more than 2 seconds of blank or low-level segment. • when the recorder is paused while recording. You can erase unnecessary marks after recording ("Erasing a track mark", page 22)
Recorded sound level		Same as the source	Adjusted automatically. Can also be adjusted manually ("Adjusting the recording level manually", page 13).

Note

- Track marks may be copied incorrectly.
- When you record from some CD players or multi-disc players using digital input.
- When the source is in shuffle or program play mode while recording using digital input. In this case, play the source in normal play mode.

Recording with digital input

This unit has a built-in sampling rate converter so that you can record programs from digital equipment using other sampling rates, such as a BS tuner or a DAT deck.



- 1 Insert a recordable MD and start recording.
For recording operations, see "Recording an MD right away" (page 6). To record from a portable CD player, set the CD player to pause and then start recording.

LINE IN (OPTICAL) jack is for both digital and analog input


The recorder automatically recognizes the type of line cable and switches to digital or analog input.

Notes


- You can make a digital recording only from an optical type output.
- When recording from a portable CD player, play it on AC power and disable the anti-skip function (such as ESP™).
- Electronic Shock Protection

To start/stop recording in sync with the source player (Synchro-recording)

You can easily make digital recordings of a digital source on an MD.
Before synchro-recording, make connections to the digital source with a digital cable, and insert a recordable MD.



- 1 Slide SYNCHRO REC to ON.
"SYNC" appears in the display.
 - 2 Press and slide REC to the right.
The recorder stands by for recording.
 - 3 Play the source sound.
The recorder starts recording when it receives the playing sound.
- To stop recording, press ■.



continued



• You cannot pause manually during synchro-recording.


• When there is no sound from the player for more than 3 seconds during synchro-recording, the recorder goes into the standby mode automatically. When the sound comes from the player again, the recorder resumes synchro-recording. If the recorder is kept in the standby mode for 5 minutes or longer, the recorder stops automatically.

Notes

- Do not switch SYNC HRO REC after step 2. Recording may not be done properly.
- When recording in monaural, follow steps 1 and 2 of "Recording in monaural for double the normal recording time" (page 13) before synchro-recording.

Recording from a microphone

Connect a stereo microphone (ECM-717, ECM-MS907, ECM-MS957, etc.; not supplied) to the MIC (PLUG IN POWER) jack.



- 1 Select the sensitivity with MIC SENS (at the bottom of the recorder). Usually, set it to HIGH. When recording loud sounds such as a live concert, set it to LOW.


- 2 Insert a recordable MD and start recording.
Press and slide REC to the right. "REC" lights up and recording starts. For other operations, see "Recording an MD right away!" (page 6).

Note

To record from a microphone, you must first disconnect any digital source. If connected, the recorder will not switch to microphone input.

Recording in monaural for double the normal recording time

For longer recordings, choose to record in monaural. The recording time becomes double the normal.



- 1 While pressing **II**, press and slide REC to the right.
The recorder stands by for recording.
- 2 Press MODE.
"Mono REC" appears in the display, and the recorder switches to monaural recording.
Press MODE again to record in stereo.

- 3 Press **II** again to start recording.
- 4 Play the sound source.

To stop recording, press ■.


The recorder switches back to stereo recording when you record the next time.

Notes


- If you record a stereo source in monaural, the sounds from left and right will be mixed.
- You cannot record in monaural if SYNC HRO REC is slid to ON.
- The MDs recorded in monaural can be played back only with an MD player/recorder that has the monaural playing function.

Adjusting the recording level manually (Manual recording)

When you record with an analog input, the sound level is adjusted automatically. If necessary, you can set the level manually.




- 1 While holding down **II**, press and hold REC to the right for more than 2 seconds.
"Manual REC" appears and the recorder stands by for recording. To return to the automatic control while the recorder is in standby mode, press and hold REC to the right again for more than 2 seconds.



- 2 Play the source.

continued

While observing the level meter in the display, adjust the recording level by pressing ►► (+) or ◄◄ (-). Set the level so that it hits the seventh indicator from the bottom at maximum input level.



Note

Adjust the recording level while the recorder is in standby mode. You cannot adjust it while recording.

Press II again to start recording.


To stop recording, press ■.

The recording level control is switched back to automatic control.

💡 When you record with microphone input, select the sensitivity with MIC SENS (page 12).


Checking the remaining time or the recording position

On the recorder



Press DISPLAY while recording or in stop mode. Each time you press the button, the display changes as follows.

Position pointer (shows the current location on the MD)




While recording

A	B
Elapsed time	Track number
Remaining time for recording	Track number
Current time ¹⁾	Current date ²⁾
³⁾ Appears only when the clock is set.	


In stop mode

A	B
Elapsed time	Track number
Remaining time for recording	Track name ¹⁾
Remaining time after the current location	Disc name ²⁾
Current time ³⁾	Current date ²⁾
¹⁾ Appears only if the track has been labeled.	
²⁾ Appears only when the clock is set.	

On the remote control



Press DISPLAY while recording or in stop mode. Each time you press the button, the display changes as follows.



While recording

A	B
Track number	Elapsed time
Track number	Remaining time for recording
—	Current time ¹⁾
¹⁾ Appears only when the clock is set.	

In stop mode

A	B
Track number	Elapsed time
Track number	Track name ¹⁾
Number of tracks in the disc	Disc name ²⁾
—	Current time ³⁾
¹⁾ Appears only if the track has been labeled.	
²⁾ Appears only when the clock is set.	

To know the recording condition

The REC indicator lights up or flashes according to the recording condition.

Recording condition

While recording	REC indicator
	lights up
	flashes according to the loudness of the source while recording with a microphone (voice mirror)


Recording standby flashes
Less than 3 minutes¹⁾ flashes slowly
recording time available

A track mark has been added goes off momentarily


💡 If you want to check the playing position of track name while playing, see page 19.

Setting the clock to stamp the recorded time

To stamp the date and time on the MDJ when you record, you first need to set the clock.



- 1 Connect the power source. Use the supplied AC power adaptor.
- 2 Press **CLOCK SET** at the bottom of the recorder. Use a pointed object. The digits of the year flash.



- 3 Change the current year by pressing **←←** or **→→**. To change the digits rapidly, keep pressing **←←** or **→→**.

- 4 Press **▶** to enter the year. The digit of the month flashes.

- 5 Repeat steps 3 and 4 to enter the current month, date, hour, and minute.

When you press **▶** to enter the minute, the clock starts operating.

If you make a mistake while setting the clock

Press **■**, and set the clock again from step 2. You can skip a step by pressing **▶**.

To display the current time

When the recorder is not operating or while recording, press **DISPL.AY** repeatedly until the current time appears in the display.

To display the time in the 24-hour system

While setting the clock, press **DISPL.AY** to display the time in the 12-hour system, press **DISPL.AY** again.


Charging the built-in battery for the clock

When you use the recorder for the first time or after a long period of disuse, charge the built-in battery. After setting the clock, leave the recorder connected to the AC power for about 2 hours to charge the built-in battery. Once charged, the built-in battery should last about a month without connecting to any of the power sources. The recorder will automatically charge the built-in battery while connected to AC power, dry batteries or a rechargeable battery.


► Various ways of playback

Selecting the track number or track name directly

You can select the desired track directly by using the vertical jog dial.



- 1 Rotate the jog dial to select a track, and press **▶** to play the selected track.




Rotate to select. **Press to play.**

When you rotate the jog dial, the track name* appears in the display. To play the selected track, press the jog dial.
* If the track has not been labeled, only the track number appears in the display.

◀ If you select a track in shuffle play mode, shuffle play starts from the selected track.


Playing tracks repeatedly

You can play tracks repeatedly in three ways — all repeat, single repeat, and shuffle repeat.



- 1 Press **MODE** (**CLAY** **MC**) or the remote control while the recorder is playing an MD. Each time you press the button, the play mode indication changes as follows.


Ex: Display on the main unit



Indication	Play mode
none	All the tracks are played once.
" CLAY "	All the tracks are played repeatedly.
" CLAY " (all repeat)	A single track is played repeatedly.
" CLAY " (single repeat)	All the tracks are played repeatedly in random order.
" CLAY SHUF " (shuffle repeat)	

Emphasizing bass (DIGITAL MEGA BASS)

Mega Bass function intensifies low frequency sound for richer quality audio reproduction. It affects only the sound from the headphones.



DIGITAL MEGA BASS

- 1 Press DIGITAL MEGA BASS. Each time you press DIGITAL MEGA BASS, the Mega Bass indication changes as follows.



Mega Bass indication


Indication	Play mode
none	Normal play
"BASS"	Mega Bass (moderate effect)
"BASS"	Mega Bass (strong effect)

Notes

- If the sound becomes distorted when emphasizing bass, turn down the volume.
- Mega Bass function does not affect the sound being recorded.
- Mega Bass does not function when a line cable is connected to the LINE OUT jack on the recorder.

Protecting your hearing (AVLS)

The AVLS (Automatic Volume Limiter System) function keeps down the maximum volume to protect your ears.




AVLS

- 1 Set AVLS at the bottom of the recorder to LIMIT. When you try to turn the volume too high, "AVLS" appears in the display. The volume is kept to a moderate level.

Checking the remaining time or the playing position

On the recorder



DISPLAY


- 1 Press DISPLAY while playing. Each time you press DISPLAY, the display changes as follows.

Position pointer (shows the current location on the MD)




A	B
Elapsed time	Track number
Remaining time of the current track	Track name ¹⁾
Remaining time after the current location	Disk name
Recorded time ²⁾	Recorded date ³⁾
¹⁾ Appears only if the track has been labeled	
²⁾ Appears only when the clock is set	

On the remote control



DISPLAY

- 1 Press DISPLAY while playing. Each time you press DISPLAY, the display changes as follows.




A	B
Track number	Elapsed time
Track number	Track name ¹⁾
The number of tracks in the disk	Disk name ²⁾
	Recorded time ³⁾

¹⁾ Appears only if the track has been labeled
²⁾ Appears only when the clock is set

³⁾ If you want to check the remaining time or the recording position while recording or in stop mode, see Page 14

Locking the controls (HOLD)

To prevent the buttons from being accidentally operated when you carry the recorder, use this function.




- 1 Slide **HOLD** in the direction of the arrow.
On the recorder, slide **HOLD** to lock the controls of the recorder. On the remote control, slide **HOLD** to lock the controls of the remote control.

Slide **HOLD** in the opposite direction of the arrow to unlock the controls.

Connecting to a stereo system

Connect the **LINE OUT** jack of the recorder to the **LINE IN** jacks of an amplifier or a tape player with a line cable (RK-G129 or RK-G136, not supplied). The output is analog. The recorder plays the MD digitally and sends analog signals to the connected equipment.



Note

The Mega Bass does not function or will be cancelled when the **LINE OUT** jack is connected with a line cable.

▶ Editing recorded tracks

You can edit your recordings by adding/erasing track marks or labeling tracks and MDs. Premastered MDs cannot be edited.

Notes on editing


- Do not move or jog the recorder while "Track Edit" is flashing in the display.
- You cannot edit tracks on an MD that is record-protected. Before editing tracks, close the tab on the side of the MD.

*TDC = Table of Contents

Erasing tracks

To erase a track

Note that once a recording has been erased, you cannot retrieve it. Make sure of the track you are erasing.



- 1 Press **ERASE** while playing the track you want to erase.
"Erase OK?" and "Push Erase" appear in the display alternately, and the recorder plays the selected track repeatedly. To cancel erasing, press ■.

- 2 Check the track number in the display and press **ERASE** again.
The track is erased from the MD and the remaining tracks are renumbered.


To erase a part of a track

Add track marks at the beginning and the end of the part you want to erase, then erase the part.

To erase the whole disc

You can quickly erase all the tracks and data of the MD at the same time.

Note that once a recording has been erased, you cannot retrieve it. Be sure to check the contents of the disc you want to erase.



- 1 In stop mode, keep pressing **ERASE** and press and slide **REC** to the right.
"All Erase?" and "Push Erase" appear in the display alternately. To cancel erasing, press ■.
- 2 Press **ERASE** again.
"Track Edit" flashes in the display. When erasing finishes, "Hi ANK Disc" appears.


Adding a track mark

You can add track marks so that the port after the new track mark is counted as a new track.

The track numbers will increase as follows.

1	2	3	4	
↓ Track marking				
1	2	3	4	5

Track numbers increase



- 1 While playing or pausing an MD, press T MARK on the recorder at the point you want to mark. "MARK ON" appears in the display, and a track mark is added. The track number will increase by one.

To add track marks while recording

Press T MARK on the recorder or TRACK MARK on the remote control.

Note


TRACK MARK on the remote control does not function during playback.

Erasing a track mark

When you record with analog (line) input, unnecessary track marks may be recorded where recording level is low. You can erase a track mark to combine the tracks before and after the track mark. The track numbers will change as follows.

1	2	3	4	
↓ Erase a track mark				
1	2	3		

Track numbers decrease



- 1 While playing the track with the track mark you want to erase, press II to pause.

- 2 Find the track mark by pressing I◀▶ slightly.

For example, to erase the third track mark, find the beginning of the third track. "00:30" appears in the display.

- 3 Press T MARK to erase the mark.

"MARK OFF" appears in the display. The track mark is erased and the two tracks are combined.

When you erase a track mark, the date, time, and name assigned to the mark are also erased.


Moving recorded tracks

You can change the order of the recorded tracks.

Before moving			
Track A	Track B	Track C	Track D
1	2	3	4

After moving
moving Track C from the third to the second track.

Track A	Track C	Track B	Track D
1	2	3	4



- 1 While playing the track you want to move, keep pressing ► and press TITLE/ENTER.

The recorder plays the selected track repeatedly. For the example above, "MOV03->003" appears in the display.

- 2 Rotate the vertical jog dial to select the new track position.


For the example above, rotate the jog dial until "MOV03->002" appears in the display. To cancel moving, press ■.

- 3 Press TITLE/ENTER again. Moving is completed and the recorder plays the moved track.

You can also move the track by pressing the jog dial in step 3.

Labeling recordings

You can label the MDs and tracks you recorded with letters, numbers, and marks. Each label can be made up of up to 200 characters, and each MD can hold up to 1700 characters.



- 1 To label a track, play the track you want to label. To label an MD, insert the recordable MD you want to label. If an MD is already inserted, press ■ to stop.

- 2 Press TITLE/ENTER. If you have selected a track in step 1 above, the recorder will play that track repeatedly. A cursor flashes in the display.

- 3 Use the vertical jog dial to select and enter a character.



Rotate to select. Press to enter.

Rotate the jog dial to select a character, and press the jog dial to enter the selected character. The cursor shifts rightward and stands by for the input of the next character.

continued

Press	To
▶	Switch between capital letters, small letters, and marks/numbers.
◀▶ / ▶▶	Move the cursor to the left or right.
END SEARCH	Insert a space.
ERASE	Delete a character.
■	Cancel labeling.

4 Repeat step 3 until you have entered all the characters for the label.

5 Press TITLE/ENTER. Labeling is completed.

To cancel labeling, press ■.

Available characters

- Capital and small letters of the English alphabet
- Numbers 0 to 9
- " ' " # \$ % & () * + , - . : ; < = > ? [\] ^ _ { | } ~

To relabel recordings

Follow steps 1 and 2 to display the label of the track or MD. Enter a new character over the one you want to change; then press TITLE/ENTER.

Notes

- You cannot relabel premastered MDs or label MDs that have not been recorded.
- The recorder is able to display, but cannot label using, Japanese "Katakana" characters.

► Power sources

You can use the recorder on house current or as follows.


- In the recorder ...
- a lithium ion rechargeable battery (supplied)
 - With supplied battery case ...
 - dry batteries (not supplied)

It is preferable to use the recorder on house current when recording for a long time.


Using a lithium ion rechargeable battery

Before using the supplied LJP-8 lithium ion rechargeable battery for the first time, charge it in the recorder.

- 1** Connect the supplied AC power adaptor to wall outlet.



- 2** Insert the LJP-8 into the recorder and close the lid.



Battery indication appears in the display and charging starts. When charging is completed, battery indication disappears.

Charging time

- 80% Approx. 2 hours
- 100% Approx. 3 hours

(To charge a completely discharged battery)




You can use the recorder while charging.

Notes


- Be sure to use the supplied AC power adaptor.
- Charging time may vary depending on the battery condition.

Using dry batteries

1 Attach the supplied battery case



2 Insert two LR6 (size AA) dry batteries (not supplied)



Battery life^{*)}

Batteries	Recording	Playback
LiP-8 lithium ion rechargeable battery	Approx. 4 hours	Approx. 7 hours
Two LR6 (size AA) Sony alkaline dry batteries	-----	Approx. 12 hours
LiP-8 + Two LR6 (size AA)	-----	Approx. 22 hours

- *The battery life may be shorter due to operating conditions and the temperature of the location.
- *When you record, use a fully charged rechargeable battery.
- *Recording time may differ according to the alkaline batteries.

When to replace the batteries

When the dry batteries or rechargeable battery are weak, flashing 4 or 7 (LOW BATT*) appears in the display. Replace the dry batteries or charge the rechargeable battery.

►Additional information

Precautions

On safety

Do not put any foreign objects in the DC IN 6 V jack.

On power sources

- Use house current, lithium ion rechargeable battery, two LR6 (size AA) batteries, or car battery.
- For use in your house: Use the AC power adaptor supplied with this recorder. Do not use any other AC power adaptor since it may cause the recorder to malfunction.

Polarity of the plug



- The recorder is not disconnected from the AC power source (mains) as long as it is connected to the wall outlet, even if the recorder itself has been turned off.
- If you are not going to use this recorder for a long time, be sure to disconnect the power supply (AC power adaptor, dry batteries, rechargeable battery, or car battery cord). To remove the AC power adaptor from the wall outlet, grasp the adaptor plug itself, never pull the cord.
- For use in the car: Use the CTA-9 car connecting pack and the DC C-4260 car battery cord (not supplied).

On heat build-up

Heat may build up in the recorder if it is used for an extended period of time. In this case, leave the recorder turned off until it cools down.

On installation

- Never use the recorder where it will be subjected to extremes of light, temperature, moisture or vibration.
- Never wrap the recorder in anything when it is being used with the AC power adaptor. Heat build-up in the recorder may cause malfunction or damage.

On the headphones

Road safety

Do not use headphones while driving, cycling, or operating any motorized vehicle. It may create a traffic hazard and is illegal in many areas. It can also be potentially dangerous to play your recorder at high volume while walking, especially at pedestrian crossings. You should exercise extreme caution or discontinue use in potential hazardous situations.

Preventing hearing damage

Avoid using headphones at high volume. Hearing experts advise against continuous, loud and extended play. If you experience ringing in your ears, reduce the volume or discontinue use.

Caring for others

Keep the volume at a moderate level. This will allow you to hear outside sounds and to be considerate of the people around you.

On the MiniDisc cartridge

- Do not break open the shutter.
- Do not place the cartridge where it will be subject to light, extreme temperatures, moisture or dust.

On cleaning

- Clean the recorder casing with a soft cloth slightly moistened with water or a mild detergent solution. Do not use any type of abrasive pad, scouring powder or solvent such as alcohol or benzene as it may ruin the finish of the casing.
- Wipe the disc cartridge with a dry cloth to remove dirt.
- Dust on the lens may prevent the unit from operating properly. Be sure to close the disc compartment lid after inserting or ejecting an MD.

Notes on batteries

Incorrect battery usage may lead to leakage of battery fluid or bursting batteries. To prevent such accidents, observe the following precautions:


- Install the + and – poles of the batteries correctly.
- Do not install new and used batteries or different kinds of batteries together.
- Do not try to recharge dry batteries.
- When the recorder is not to be used for a long time, be sure to remove the batteries.
- If a battery leak should develop, carefully and thoroughly wipe away battery fluid from the battery compartment before inserting new ones.

Note on mechanical noise

The recorder gives off mechanical noise while operating, which is caused by the power-saving system of the recorder and it is not a problem.


To protect a recorded MD

To record-protect an MD, slide open the tab at the side of the MD. In this position, the MD cannot be recorded. To record again, slide the tab back so the tab is visible.



Note on digital recording

This recorder uses the Serial Copy Management System, which allows only first-generation digital copies to be made from premastered software. You can only make copies from a home-recorded MD by using the analog (line out) connections.



If you have any questions or problems concerning your recorder, please consult your nearest Sony dealer.

Troubleshooting

Should any problem persist after you have made these checks, consult your nearest Sony dealer.

Symptom	Cause/Solution
The recorder does not work or works poorly.	<ul style="list-style-type: none"> • Audio sources may not be securely connected. <ul style="list-style-type: none"> ➔ Disconnect the audio sources once and connect them again (pages 6, 11). • Moisture has condensed inside the recorder. <ul style="list-style-type: none"> ➔ Take the MD out and leave the recorder in a warm place for several hours until the moisture evaporates. • The rechargeable battery or dry batteries are weak (LOW or "LOW BATT" flashes). <ul style="list-style-type: none"> ➔ Charge the rechargeable battery or replace the dry batteries (pages 25, 26). • The rechargeable battery or dry batteries have been installed incorrectly. <ul style="list-style-type: none"> ➔ Install the batteries correctly (page 26). • You pressed a button while the disc indication was rotating quickly. <ul style="list-style-type: none"> ➔ Wait until the indication rotates slowly. • The recording volume is too low. <ul style="list-style-type: none"> ➔ When recording digitally from a portable CD player, you did not use AC power or did not disable the anti-skip function such as FSP (page 11). • The analog recording was made using a connecting cord with an attenuator. <ul style="list-style-type: none"> ➔ Use a connecting cord without an attenuator (page 6). • The AC power adaptor was unplugged during recording or a power outage occurred. • While operating, the recorder received a mechanical shock, too much static, abnormal power voltage caused by lightning, etc. <ul style="list-style-type: none"> ➔ Restart the operation as follows. <ol style="list-style-type: none"> 1 Disconnect all the power sources. 2 Leave the recorder for about 30 seconds. 3 Connect the power source. • The headphones plug is not firmly connected. <ul style="list-style-type: none"> ➔ Plug in the plug of the headphones firmly to the remote control. Plug in the plug of the remote control firmly to 3/REMOTE. • Volume is too low. <ul style="list-style-type: none"> ➔ Adjust the volume by pressing VOL (+/-) (VOL +/- on the remote controller). • AV1 S is on. <ul style="list-style-type: none"> ➔ Slide AV1s to NORM (page 18).
No sound comes through the headphones.	

Symptom	Cause/Solution
An MD is not played from the first track.	<ul style="list-style-type: none"> Disc playing stopped before it came to the last track. <ul style="list-style-type: none"> ➔ Press ▶◀▶ repeatedly or open and close the lid once to go back to the beginning of the disc, and restart playing after checking the track number in the display.
Playback sound skips.	<ul style="list-style-type: none"> The recorder is placed where it receives continuous vibration. <ul style="list-style-type: none"> ➔ Put the recorder on a stable place. A very short track may cause sound to skip.
Sound has a lot of static.	<ul style="list-style-type: none"> Strong magnetism from a television or such device is interfering with operation. <ul style="list-style-type: none"> ➔ Move the recorder away from the source of strong magnetism.
C cannot find the track marks.	<ul style="list-style-type: none"> You pressed II after pressing ▶◀▶ or ▶▶▶. <ul style="list-style-type: none"> ➔ Press II before pressing ▶◀▶ or ▶▶▶.
C charging the rechargeable battery does not start.	<ul style="list-style-type: none"> The rechargeable battery has been inserted incorrectly or the AC power adaptor has been connected incorrectly. <ul style="list-style-type: none"> ➔ Insert the battery correctly or connect the AC power adaptor correctly.
The clock loses time or the display flashes.	<ul style="list-style-type: none"> The built-in battery for the clock is weak. <ul style="list-style-type: none"> ➔ Connect the AC power adaptor to IXX IN 6 V on the recorder and the wall outlet to charge the built-in battery. After charging, set the clock again (page 16). Note that the clock normally loses about 2 minutes per month.
The lid does not open	<ul style="list-style-type: none"> The power sources have been disconnected during playback, or the batteries have been exhausted. <ul style="list-style-type: none"> ➔ Set the power sources again, or replace the exhausted batteries with new ones.

System limitations

The recording system in your MiniDisc recorder is radically different from those used in cassette and DAT decks, and is characterized by the limitations described below. Note, however, that these limitations are due to the inherent nature of the MD recording system itself and not to mechanical causes.

Symptom	Cause
"TR FULL" appears even before the disc has reached the maximum recording time (60 or 74 minutes).	When 254 tracks have been recorded on the disc, "TR FULL" appears regardless of the total recorded time. More than 254 tracks cannot be recorded on the disc. To continue recording, erase unnecessary tracks.
"TR FULL" appears even before the disc has reached the maximum track number or recording time	Repeated recording and erasing may cause fragmentation and scattering of data. Although these scattered data can be read, each fragment is counted as a track. In this case, the number of tracks may reach 254 and further recording is not possible. To continue recording, erase unnecessary tracks.
Track marks cannot be erased.	When the data of a track is fragmented, the track mark of a fragment under 12 seconds long cannot be erased. You cannot combine a track recorded in stereo and a track recorded in monaural, nor can you combine a track recorded with digital connection and a track recorded with analog connection.
The remaining recording time does not increase even after erasing numerous short tracks	Tracks of under 12 seconds in length are not counted and so erasing them may not lead to an increase in the recording time.
The total recorded time and the remaining time on the disc may not total the maximum recording time (60 or 74 minutes).	Recording is done in minimum units of 2 seconds each, no matter how short the material. Even if the last unit of recording is less than 2 seconds, it is counted as a unit of 2 seconds. Then 2 seconds' space is put before recording starts again to prevent the last unit of the previous track from being erased. The contents recorded may thus be shorter than the maximum recording capacity.
The edited tracks may exhibit sound dropout during search operations.	The fragmentation of data may cause sound dropout while searching because the tracks are played in higher speed than normal playback.

Messages

If the following error messages flash in the display window, check the chart below.

Error message	Meaning/Remedy
BLANK DISC	<ul style="list-style-type: none"> • An MD with no recording on it is inserted. <ul style="list-style-type: none"> ➔ Insert a recorded MD.
DISC ERR	<ul style="list-style-type: none"> • The recorder cannot read the disc (it's scratched or dirty). <ul style="list-style-type: none"> ➔ Reinsert or replace the disc.
DISC FULL	<ul style="list-style-type: none"> • There is no more space to record on the disc (less than 12 seconds available). <ul style="list-style-type: none"> ➔ Replace the disc.
Data Save	<ul style="list-style-type: none"> • The MD player is recording information (sounds) from the memory to the disk. <ul style="list-style-type: none"> ➔ Wait until this process is completed. Do not expose the player to any physical shock, nor disrupt power supply.
The Edit	<ul style="list-style-type: none"> • The MD player is recording information (track start and end position) from the memory to the disk. <ul style="list-style-type: none"> ➔ Wait until this process is completed. Do not expose the player to physical shock, nor disrupt power supply.
BUSY	<ul style="list-style-type: none"> • You tried to operate the recorder while it was accessing the recorded data. <ul style="list-style-type: none"> ➔ Wait until the message goes out (in rare cases, it may take 2-3 minutes)
NAME FULL	<ul style="list-style-type: none"> • You tried to enter more than 200 characters for a track or disc name or the total characters entered in an MD is more than 1700. <ul style="list-style-type: none"> ➔ Enter the characters within the limit.
HIGH m	<ul style="list-style-type: none"> • Voltage of the power supply is too high (The supplied AC power adaptor or the recommended car battery cord is not used). <ul style="list-style-type: none"> ➔ Use the supplied AC power adaptor or the recommended car battery cord.
HOLD	<ul style="list-style-type: none"> • The recorder is locked. <ul style="list-style-type: none"> ➔ Slide HOLD against the arrow to unlock the recorder (page 20).
LOW BATT	<ul style="list-style-type: none"> • Batteries are weak. <ul style="list-style-type: none"> ➔ Charge the rechargeable battery or replace the dry batteries (pages 25, 26).
MEM OVER	<ul style="list-style-type: none"> • You tried to record when there is no indication in the display, with the recorder placed where it receives continuous vibration. <ul style="list-style-type: none"> ➔ Put the recorder on a stable place, and start recording again.

Error message

Meaning/Remedy


NO COPY	<ul style="list-style-type: none"> • You tried to make a copy from a disc that is protected by the Serial Copy Management System. You cannot make copies from a digitally connected source which was itself recorded using digital connection. <ul style="list-style-type: none"> ➔ Use analog connection instead (page 6).
NO DISC	<ul style="list-style-type: none"> • You tried to play or record with no disc in the recorder. <ul style="list-style-type: none"> ➔ Insert an MD.
NO SIGNAL	<ul style="list-style-type: none"> • The recorder could not detect digital input signals. <ul style="list-style-type: none"> ➔ Make sure that the source is connected firmly (page 11).
P/B ONLY	<ul style="list-style-type: none"> • You tried to record or edit on a pre-mastered MD (P/B means playback). <ul style="list-style-type: none"> ➔ Insert a recordable MD.
PROTECTED	<ul style="list-style-type: none"> • You tried to record or edit on a MD with the tab in the record-protect position. <ul style="list-style-type: none"> ➔ Slide the tab back (page 28).
SORRY	<ul style="list-style-type: none"> • You tried to erase a track mark while playing the MD or at the beginning of the first track. <ul style="list-style-type: none"> • You tried to erase a track mark to combine tracks (the recorder cannot combine (caused by system limitation).
TEMP OVER	<ul style="list-style-type: none"> • Head has built up in the recorder. <ul style="list-style-type: none"> ➔ Let the recorder cool down.
TR FULL	<ul style="list-style-type: none"> • There is no more space for new data when you are editing the MD. <ul style="list-style-type: none"> ➔ Erase unnecessary tracks (page 21)
TRIPROTECT	<ul style="list-style-type: none"> • You tried to record or edit on a track that is protected from erasing. <ul style="list-style-type: none"> ➔ Record or edit on other tracks.

How the MiniDisc got so small

The 2.5-inch MiniDisc, encased in a plastic cartridge that looks like a 3.5-inch diskette (see illustration above), uses a new digital audio compression technology called ATRAC (Adaptive Transform Acoustic Coding). To store more sound in less space, ATRAC extracts and encodes only those frequency components actually audible to the human ear.

Quick Random Access

Like CDs, MDs offer instantaneous random access to the beginning of any music track. Pre-mastered MDs are recorded with location addresses corresponding to each music selection. Recordable MDs are manufactured with a "User TOC Area" to contain the order of the music. The TOC (Table of Contents) system is similar to the "directory" management system of floppy disks. In other words, starting and ending addresses for all music tracks recorded on the disc are stored in this area. This lets you randomly access the beginning of any track as soon as you enter the track number (AMS), as well as label the location with a track name as you would a file on a diskette.



Contains the order and start/end points of the music.


Shock-Resistant Memory

One major drawback of optical read systems is that they can skip or mute when subjected to vibration. The MD system resolves this problem by using a buffer memory that stores audio data.

Looking at the controls


See pages in () for more details.

The recorder



- [1] Battery compartment (at the bottom) (25)
- [2] MC/MD button (17)
- [3] DISPLAY button (14, 19)
- [4] CLOCK SET button (at the bottom) (16)
- [5] MIC SENS switch (at the bottom) (12)
- [6] AVLS switch (at the bottom) (18)
- [7] DC IN 6V jack (at the rear) (6)
- [8] Display window (14, 19)
- [9] SYNCHRO REC (synchro-recording) switch (11)
- [10] MIC (PLUG IN POWER) jack (12)
- [11] LINE IN (OPTICAL) jack (6, 11)
- [12] LINE OUT jack (20)
- [13] DIGITAL MEGA BASS button (18)
- [14] (headphones)/RE/MUTE jack (8)
- [15] REC indication (14)
- [16] Vertical jog dial (17, 23)
- [17] TITLE/ENTER button (23)
- [18] (play) button (7, 9)
- [19] (search / AMS) button (7, 9)
- [20] (stop) button (7, 9)
- [21] VOL MF +/- button (9)
- [22] HOLD switch (20)
- [23] ERASE button (21)
- [24] T MARK button (22)
- [25] END SEARCH button (7)
- [26] REC (record) switch (7)
- [27] (pause) button (7, 9)
- [28] OPEN button (6)

The display window



[1] Position pointer (14, 19)

Shows the current location on the MD.
The point under recording or playing
flashes. The recorded portion lights
up.

Current location



Recorded portion

Disc length

[2] MONO (monaural) indication

[3] Play mode indication
Shows the play mode of the MD.

[4] Disc indication

Shows that the disc is rotating for

[5] SYNC (synchronizing) indication

[6] REC (recording) indication
Lights up while recording. When
flashing, the recorder is in record
standby mode.

[7] Level meter

Shows the volume of the MD being
played or recorded.

[8] AM/PM indication (16)

Lights up along with the time
indication in the 12-hour system.

[9] Mega bass indication (18)

Shows battery condition.

[10] BATTERY (battery) condition.

[11] REMAIN (remaining time/tracks)
indication (14, 19)

Lights up along with the remaining
time of the track, the remaining time
of the MD, or the remaining number
of tracks.

[12] REC DATE (recorded/current date)

indication

Lights up along with the date and
time the MD was recorded. When only
"DATE" lights up, the current date
and time are displayed.


[13] Time display (14, 19)

Shows the recorded time, current time,
elapsed time of the track or MD being
recorded or played.

[14] Character information display (14, 19)

Displays the disc and track names,
date, error messages, track numbers,
etc.

The headphones with a remote control



[2]

[3]

[4]


[5]

[6]

[7]

[8]

[9]



[1] Headphones

Can be replaced with optional

headphones.

[2] Stereo mini-plug.

[3] ■ (stop) button (7, 9)

[4] Control (9)

To play, turn to ►►►► during stop.

Turn to ►►►► during play to search
the beginning of the succeeding track,
hold in this position to fast-forward.

Turn to ◀◀◀◀ during play to search the
beginning of the preceding track;
hold in this position to rewind.

[5] HOLD switch (20)

Slide to lock the controls of the remote
control.

[6] ■ (pause) button (7, 9)

[7] ■ (AV MUTE) button (17)

[8] (DISP) button (15, 19)

[9] VOL (volume) + / - buttons (9)

[10] TRACK MARK button (22)

[11] Display window (15, 19)

For customers in the United States
Unfold the supplied headphones as
shown in the illustration below:

